



Prepare Your Home For Installation

This is a guide for preparing yourself and your home for the big day!
Please make arrangements to have everything ready prior to our installers' arrival

Quick Checklist

- ✓ Plumbing and electrical disconnected prior to install and reconnected at least 12 hours after installation
- ✓ Sinks, faucets, air gaps, fixtures and appliances that go on the countertop, unpacked and ready in area
- ✓ Countertops removed, free of nails, flat and plumb (if you will tear out)
- ✓ All items on countertops removed (if AMC will tear out)
- ✓ Drawers and all items in sink cabinet removed
- ✓ Children and pets away from the area at all times

Other Important Steps

- Remove all items under the kitchen sink and any breakables from other base cabinets. We suggest you cover with cloths the rest of the items to minimize cleaning afterwards
- Any construction creates dirt, dust and noise. Cover items and seal off other rooms
- Please keep pets and children completely away from the work area due to risk of injury, noise, dust, odors
- Designate a path and doorway for installers to come and go with the heavy materials
- Show the installers a designated work area for cutting and adjusting, if necessary. We suggest a garage or a similar area
- Driveway should be clear, free of snow or mud
- Take a break from cooking. While your kitchen is out of service, order take-out or set up a temporary food prep area in another room
- Please be present at the end of the installation to walk through, review and sign at completion. Your installers are working long and hard to give you the best possible job